








ALFACare





RevoSurface®


SKU	Product	Description	Picture	Available
RS-100-07-01	RevoSurface® Tool Kit	This single RevoSurfaceTool Kit allows you to add adjustability onto new or existing prostheses and orthoses in endless configurations.		10/1/2021
RP-000-07	Click® Reel and Lace Kit	Replacement Click Reel and 2m of Lace for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-001	Indicator Lace Kit	Replacement Indicator Lace (2m) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-101	Surface Guide 10-Pack	Replacement Surface Guide 10-Pack for RevoSurface Kits only.		10/1/2021
RP-102	Surface Collar + Surface Shim	Replacement Surface Collar and Shim for RevoFit Diagnostic & RevoSurface Kits only.		10/1/2021

RP-105	Surface Releasing Tab 5-Pack	Replacement Surface Releasing tab 5-Pack for RevoSurface Kits.		10/1/2021
BL-001	Indicator Lace - 25m Spool	Bulk Indicator Lace (25m spool) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021




RevoFit®

SKU	Product	Description	Picture	Available
RF-200-07-01	RevoFit® Lamination Kit	This single RevoFit Lamination Kit allows you to build in user-controlled adjustability anywhere on a socket.		10/1/2021
RF-200-07-10	RevoFit® Lamination Fabricators 10-Pack	Large practices, regular users and central fabricators save money and always have a kit ready to use by ordering the Fabricators 10-Pack.	<p>Contents:</p> <ul style="list-style-type: none"> ○ 10 Lamination Collars ○ 10 Lamination Tubes - 1.5m ○ 10 Click® Reels ○ 25m Indicator Lace ○ 5 Lace Feeders ○ 3 Click® Reel Tools ○ 3 Click® Reel Lock Pins 	10/1/2021
RF-201-07-01	RevoFit® Diagnostic Kit	This single RevoFit Diagnostic Kit lets you adjust even earlier in socket development. Used for validating design and function of a RevoFit system on a patient during the diagnostic socket stage only.		10/1/2021





RP-000-07	Click® Reel and Lace Kit	Replacement Click Reel and 2m of Lace for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-001	Indicator Lace Kit	Replacement Indicator Lace (2m) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-102	Surface Collar + Surface Shim	Replacement Surface Collar and Shim for RevoFit Diagnostic & RevoSurface Kits only.		10/1/2021
RP-200	Lamination Collar	Replacement Lamination Collar for RevoFit and all RevoLock Kits.		10/1/2021
RP-201	Lamination Tube - 1.5m	Replacement Lamination Tube (1.5m) for RevoFit and all RevoLock Kits.		10/1/2021
BL-001	Indicator Lace - 25m Spool	Bulk Indicator Lace (25m spool) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021

BL-201	Lamination Tube - 18m Spool	Bulk Lamination Tube (18m spool) for RevoFit and RevoLock Kits.		10/1/2021
--------	-----------------------------	---	---	-----------

RevoLock®

SKU	Product	Description	Picture	Available
RL-300-07-01	RevoLock® 4-Hole Kit	This single RevoLock 4-Hole Kit is for standard alignment fabrication.		10/1/2021
RL-301-07-01	RevoLock® Align Kit	This single RevoLock Align Kit is for transferable alignment fabrication.		10/1/2021
RL-310-00-01	RevoLock® Tool Form	The RevoLock Tool Form is a required, reusable fabrication tool for RevoLock 4-Hole Kits.		10/1/2021

RP-000-07	Click® Reel and Lace Kit	Replacement Click Reel and 2m of Lace for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-001	Indicator Lace Kit	Replacement Indicator Lace (2m) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-200	Lamination Collar	Replacement Lamination Collar for RevoFit and all RevoLock Kits.		10/1/2021
RP-201	Lamination Tube - 1.5m	Replacement Lamination Tube (1.5m) for RevoFit and all RevoLock Kits.		10/1/2021
RP-302	RevoLock® LE Threaded Insert - M10	Replacement RevoLock M10 Threaded Insert for connection to lower extremity liners. Compatible with RevoLock Snap for releasable lace attachment. Often purchased for outfitting additional patient liners.		10/1/2021

RP-303	RevoLock® Snap	Replacement RevoLock Snap connects the Revolock lace to the liner via the RevoLock LE M10 Threaded Insert.		10/1/2021
RP-305	RevoLock® Tool Form Plug 5-Pack	The RevoLock Tool Form Plug 5-Pack is used by fabrication centers to ensure they have extra plugs on hand just in case.		10/1/2021
RP-306	RevoLock® UE Threaded Insert - M6	RevoLock M6 Threaded Insert for upper extremity liners. Compatible with RevoLock 4-Hole and RevoLock Align kits. This part is NOT releasable and does not connect to the RevoLock Snap.		10/1/2021
BL-001	Indicator Lace - 25m Spool	Bulk Indicator Lace (25m spool) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021